

Partslist and mounting instruction

Order No.: 6229 BR HD Softail M8 FLFB

Article: Solo-Rack Ø 16

Fits for: Harley-Davidson Softail Fat Boy (Milwaukee-Eight 107/114), (FLFB) 2018- and Breakout (Milwaukee-Eight 107/114), (FXBR) 2018-

1 Solo-Rack

1 x Partslist and mounting instruction
 1 x Label max. load 5 kg

Mounting parts front

Use the original screw

Mounting parts rear:

1 x Hexagon socket head screw
 1 x Washer
 1 x Distancetube

DIN 912
 DIN 9021

1/4" UNC x 1 1/4" (32mm)
 M 6
 22 x 2 x 20 mm

Only Breakout:

1 x Hexagon socket head screw
 1 x Distancetube

DIN 912

1/4" UNC x 1" (25mm)
 22 x 2 x 15 mm



Photo 6229

Datum/Name	Erstellt	Geändert	Geprüft Entwicklung	Geprüft Verkauf	Freigabe
	20231220 PK				

Mounting instruction:

- Remove the passenger seat and retaining strap.
- Place distance tube Ø 22 x 20mm on the mudguard.
- Slide Solo-rack between seat and mudguard.
- Mount the Solo-rack with the mounting parts listed below, align and screw everything tight.

- Tightening torques for bolts and nuts like from the manufacturer given.
- If not given: 4 M: 3 Nm - M of 5: 5,9 Nm - M of 6: 10 Nm - M of 8: 25 Nm - M of 10: 49 Nm - M of 12: 85 nm).
- Mount the screws, if necessary, with liquid screw protection.

Care and servicing:

To reach a long live span of our chromium-plated articles they should be cleaned regularly and be treated with customary chrome care means.

With powder coated articles a regular cleaning is important. Damages (e.g. by rockfall) can be mended with colour.

By both versions we recommend about the winter the spraying or rubbing with corrosion protection oil or silicone.

All fixing bolts must be checked at regular intervals (max. 6 months).

We wish you a lot of joy and accident-free journey with our motorcycle accessories.